

Lasergraph DSP Manual

jr.Live! Live Mode V3.1

OHM64 Midi assignment

btn id: 0 MIDI: nn 41 LED:	btn id: 30 MIDI: nn 93 LED:	btn id: 60 MIDI: cc 68 LED:	knob id: 137 MIDI: cc 10
btn id: 1 MIDI: nn 43 LED:	btn id: 31 MIDI: nn 95 LED:	btn id: 61 MIDI: cc 69 LED:	knob id: 138 MIDI: cc 26
btn id: 2 MIDI: nn 45 LED:	btn id: 32 MIDI: nn 42 LED:	btn id: 62 MIDI: cc 70 LED:	knob id: 139 MIDI: cc 27
btn id: 3 MIDI: nn 47 LED:	btn id: 33 MIDI: nn 44 LED:	btn id: 63 MIDI: cc 71 LED:	knob id: 140 MIDI: cc 28
btn id: 4 MIDI: nn 69 LED:	btn id: 34 MIDI: nn 46 LED:	btn id: 64 MIDI: cc 82 LED:	knob id: 141 MIDI: cc 29
btn id: 5 MIDI: nn 71 LED:	btn id: 35 MIDI: nn 49 LED:	btn id: 65 MIDI: cc 80 LED:	knob id: 142 MIDI: cc 22
btn id: 6 MIDI: nn 72 LED:	btn id: 36 MIDI: nn 51 LED:	btn id: 66 MIDI: nn 1 LED:	knob id: 143 MIDI: cc 23
btn id: 7 MIDI: nn 74 LED:	btn id: 37 MIDI: nn 54 LED:	btn id: 67 MIDI: nn 2 LED:	knob id: 144 MIDI: cc 24
btn id: 8 MIDI: nn 48 LED:	btn id: 38 MIDI: nn 56 LED:	btn id: 68 MIDI: nn 3 LED:	knob id: 145 MIDI: cc 25
btn id: 9 MIDI: nn 50 LED:	btn id: 39 MIDI: nn 58 LED:	btn id: 69 MIDI: nn 4 LED:	knob id: 146 MIDI: cc 8
btn id: 10 MIDI: nn 52 LED:	btn id: 40 MIDI: nn 61 LED:	btn id: 70 MIDI: nn 5 LED:	knob id: 147 MIDI: cc 9
btn id: 11 MIDI: nn 53 LED:	btn id: 41 MIDI: nn 63 LED:	btn id: 71 MIDI: nn 6 LED:	knob id: 148 MIDI: cc 20
btn id: 12 MIDI: nn 76 LED:	btn id: 42 MIDI: nn 66 LED:	btn id: 72 MIDI: nn 7 LED:	knob id: 149 MIDI: cc 3
btn id: 13 MIDI: nn 77 LED:	btn id: 43 MIDI: nn 68 LED:	btn id: 73 MIDI: nn 8 LED:	knob id: 150 MIDI: cc 14
btn id: 14 MIDI: nn 79 LED:	btn id: 44 MIDI: nn 70 LED:	btn id: 74 MIDI: nn 36 LED:	knob id: 151 MIDI: cc 15
btn id: 15 MIDI: nn 81 LED:	btn id: 45 MIDI: nn 73 LED:	btn id: 75 MIDI: nn 38 LED:	knob id: 152 MIDI: cc 30
btn id: 16 MIDI: nn 55 LED:	btn id: 46 MIDI: nn 75 LED:	btn id: 76 MIDI: nn 40 LED:	knob id: 153 MIDI: cc 31
btn id: 17 MIDI: nn 57 LED:	btn id: 47 MIDI: nn 78 LED:	btn id: 77 MIDI: nn 36 LED:	nn = note number
btn id: 18 MIDI: nn 59 LED:	btn id: 48 MIDI: nn 80 LED:	btn id: 78 MIDI: nn 38 LED:	cc = controller
btn id: 19 MIDI: nn 60 LED:	btn id: 49 MIDI: nn 82 LED:	btn id: 79 MIDI: nn 40 LED:	cc/bnd = controller or bend
btn id: 20 MIDI: nn 83 LED:	btn id: 50 MIDI: nn 85 LED:	btn id: 80 MIDI: cc 81 LED:	
btn id: 21 MIDI: nn 84 LED:	btn id: 51 MIDI: nn 87 LED:	slid id: 128 MIDI: cc 0	
btn id: 22 MIDI: nn 86 LED:	btn id: 52 MIDI: nn 90 LED:	slid id: 129 MIDI: cc 1	
btn id: 23 MIDI: nn 88 LED:	btn id: 53 MIDI: nn 92 LED:	slid id: 130 MIDI: cc 2	
btn id: 24 MIDI: nn 62 LED:	btn id: 54 MIDI: nn 94 LED:	slid id: 131 MIDI: cc 4	
btn id: 25 MIDI: nn 64 LED:	btn id: 55 MIDI: nn 96 LED:	slid id: 132 MIDI: cc 18	
btn id: 26 MIDI: nn 65 LED:	btn id: 56 MIDI: cc 64 LED:	slid id: 133 MIDI: cc 5	
btn id: 27 MIDI: nn 67 LED:	btn id: 57 MIDI: cc 65 LED:	slid id: 134 MIDI: cc 6	
btn id: 28 MIDI: nn 89 LED:	btn id: 58 MIDI: cc 66 LED:	slid id: 135 MIDI: cc 7	
btn id: 29 MIDI: nn 91 LED:	btn id: 59 MIDI: cc 67 LED:	slid id: 136 MIDI: cc 16	

Flip Xfader

B8 id: [73]
OUTPUT
value 8
type note
update